

A U D I O + V I D E O

MAIN ROOM

TO PLAY YOUR MUSIC FROM Your Device IN THE MAIN ROOM VIA BLUETOOTH:

Use Wyred 4 Sound **bLINK bluetooth receiver** (small black square box with antenna and W squiggle graphic on top). To pair, Press/hold "**PAIR**" button (will blink slowly). Press again (blinks fast). To reconnect press 2x. Try again, if needed, it'll work eventually.

Your device: "**Wyred4Sound**" should appear on your bluetooth list.

Linn Unidisk gray remote: SOURCE TO "**DIG 4**" (Source displayed on black Linn Unidisk box). Use Linn remote for volume.

TO PLAY MUSIC FROM Your Device IN THE MAIN ROOM VIA APPLE AIRPLAY:

iTunes Speaker Select on your device: "**MAIN**".

Linn Unidisk gray remote: SOURCE TO "**DIG 3**" (Source displayed on the black unidisk box). Use Linn remote for volume.

TO PLAY DVD's or CD's IN THE MAIN ROOM: (sound is via the audio system)

Roku TCL TV remote: (DVDs only) POWER TO "**ON**" then SELECT "**DVD**" ICON (using Roku remote).

Arcam Player: POWER "**ON**", then load DVD (or CD). Control DVD with Arcam remote.

Linn Unidisk gray remote: SOURCE TO "**AUX 1**" (Source displayed on black unidisk box). Use Linn remote for volume.

TO WATCH STREAMING TV (HBO, Netflix, Hulu, Amazon, Youtube TV). These are FREE, please **DON'T SIGN OUT!**

Roku TCL TV remote: POWER "**ON**" then SELECT desired network ICON. (Sound is via the audio system)

If you are prompted, select user "**COSMO**." If you want to stream SHOWTIME, VUDU, ESPN, etc, you will need your own account.

Linn Unidisk remote: SOURCE TO "**TV**" (Source on unidisk box). (Control volume with Linn **AND/OR** Roku remotes).

TO CHROMECAST FROM Your Device TO THE TV (Sound is via the audio system).

Roku TCL TV remote: POWER "**ON**" then SELECT "**CHROMECAST**" ICON.

Linn Unidisk remote: SOURCE TO "**TV**" (Source on unidisk box). (Control volume with Linn **AND/OR** Roku remotes).

BEDROOM

TO PLAY CASSETTE TAPES IN THE BEDROOM:

Marantz Receiver: Press "**ON**" and "**TAPE MONITOR 1**" button (control volume/etc. with Marantz).

Nakamichi Cassete Deck: Cassette tapes are in the top right drawer of the desk in the main room.

TO PLAY YOUR FROM Your Device VIA BLUETOOTH IN THE BEDROOM:

Marantz Receiver: Press "**ON**" and "**TAPE MONITOR 2**" button (control volume/etc. with Marantz).

AURIS BLUME Bluetooth receiver: Pair it with your device. You may have to do the standard unplug/re-plug protocol.

TO PLAY MUSIC FROM Your Device VIA APPLE AIRPLAY IN THE BEDROOM:

Marantz Receiver: Press "**ON**" and turn selector clockwise knob to "**AUX**" (both Tape Monitor buttons should be OFF).

iTunes Speaker Select on your device: "**BEDROOM**".

TO PLAY MUSIC FROM Your Device VIA BLUETOOTH IN THE SHOWER

JBL CLIP: Press "**ON**" button on the side of the speaker. Pair it with your device. Control volume using +/- buttons on the front of the speaker. To enhance your experience, try listening to the **PSYCHO** film soundtrack while showering.

SEE NOTES ON NEXT PAGE...

AUDIO + VIDEO NOTES:

1. **Don't touch buttons on black Linn Unidisk box. Big No No. Seriously, only use Linn remote.**
2. To set **SOURCE** on gray Linn remote- use little teeny tiny buttons labelled (SRC+) and (SRC-).
3. When watching TV if there is no sound, try adjusting volume using buttons on the side of the Roku remote.
4. The black Linn Unidisk is a fantastic pre-amplifier. It is also a fantastic DAC (Digital Analog Converter). It also is a broken CD/DVD player. There is another disc player, so no worries.
5. The amplifier and Unidisk are always on, so there is no need to touch them. They sleep when not in use.
6. To select Airplay or Chromecast on your device, don't ask me. It's different on every device. When using Chrome, click on the 3 vertical dots on the top right of the browser window and select "**Cast**". Apple music uses the same icon for Airplay that is used for bluetooth. It is concentric circles emanating from a loud triangle. Airplay can be routed to either the main room stereo or the bedroom stereo.
7. To use Airplay, you must be connected to wi-fi network "TWO." Airplay sounds better and is simpler than Bluetooth
8. For best sound quality, set volume on your device to near maximum then adjust volume with Linn remote.
9. bLink Bluetooth will disconnect when you leave home. To reconnect, press/hold the pair button for a few seconds. The pairing function doesn't work nearly as well as \$10 earbuds, but this thing costs more than most wedding rings.
10. In the unlikely event that you didn't bring your own, my vintage tape collection is in the top right drawer of the desk in the main room. "Cassettes" were an ancient recording media used by your grandparents in the mid-20th century. Research by scientists proved that cassettes enhances the *experience* of psychedelic drugs and blacklight posters.
11. There are numerous HDMI cables in the coffee table drawer which can connect your device to the TV. I don't know squat about video, but supposedly/hopefully all of your cable gear needs covered by this kit.
12. Sorry that this is so damn complicated. Hopefully the sultry sound quality makes it worth it for you.